

PRESIDENT MADISON

Clarifier Modification

- 1) Cut D52 and R148. Find R174 and solder a wire across the resistor.
- 2) Find the **RED** wire that comes off the clarifier control and cut it just before it connects to the PCB. Take that wire and solder it to **GROUND** on the PCB
- 3) Cut the **orange** wire just like the **red** wire but solder this wire to pin # 3 if IC-4 the MB3756 IC regulator.

Extra Channel mods for the MB8719 PLL

