


## ALINCO EMS-42 MICROPHONE.

view from front of transceivers



PIN 1 MIC.  
PIN 2 PTT.  
PIN 3 DOWN.  
PIN 4 UP.  
PIN 5 DC VOLTS.  
PIN 6 N/C / REMOTE  
PIN 7 MIC GROUND / SCREEN.  
PIN 8 GROUND.